

AVerAl Carrier Board and Box PC EN713-AAE9/ EN713/ NX213B

Designed for NVIDIA® Jetson Nano/ Xavier NX Module







AVerMedia Technologies, Inc.

No. 135, Jian 1st Rd., Zhonghe Dist., New Taipei City 23585, Taiwan

Tel: 886-2-2226-3630 Fax: 886-2-3234-4842

Sales and Marketing: Contact

Technical Support: Professional User





Table of Contents

Preface	4
1.0 Introduction	8
1.1 Product Specifications	8
2.0 Product Overview	10
2.1 Block Diagram	10
2.2 Top View of Carrier Board	11
2.3 Connector Summary	13
2.4 Switch Summary	13
3.0 Feature Description	14
3.1 Connector and Switch Locations	14
3.2 10/100Mb 4-port Ethernet Connectors	15
3.3 1Gb single-port Ethernet Connector	16
3.4 260-Pin SODIMM Connector	16
3.5 SATA Power Wafer and SATA Connector	17
3.6 Fan Wafer	17
3.7 Mic and Speaker Connector	18
3.8 USB 3.1 Gen 1 2-Port Connector	18
3.9 HDMI Video Output Connector	18
3.10 USB/OTG Micro-Type Connector	19
3.11 RS-485 Connector	19
3.12 54VDC Power Jack	20
3.13 20-Pin Header	20
3.14 Mini Card Connector	21
3.15 RTC Battery Connector	21
3.16 Force Recovery Button	23
3.17 Power on Button	23
2 18 /L-Din DID Switch	2/



3.19 Other Switch and Jumpers	24
4.0 Installation	25
5.0 Software	25
6.0 Force Recovery Mode	26
7.0 Power Consumption	27



Disclaimer

The information contained in this user manual, including but not limited to any product specification is subject to change without notice. AVerMedia assumes no liability for any damages incurred directly or indirectly from any technical or typographical errors or omissions contained herein or for discrepancies between the product and the user manual.

Technical Support

If you experience the difficulty after reading this manual and/or using the product, please contact the reseller from which you purchased the product. In most cases, the reseller can help you with the product installation and the difficulty you encountered.

In case the reseller is not able to resolve your problem, our highly capable global technical support team can certainly assist you. Our technical support section is available 24 hours a day and 7 days a week through our website, with the click here. For more contact information, you may find it in the section of AVerMedia Global Offices.

Contact Enquiry:

For more information of our products, pricing, and order placement, please fill in our inquiry form here, we will contact you within 24 hours.

Download User Manual

Please click this link, <u>here</u>, to download the file of this user manual from AVerMedia website.

Revision History

Revision	Date	Updates
1.00	02/24/2021	Initial release.



AVerMedia Global Offices

https://www.avermedia.com/professional/contact

Headquarters

Taiwan Office

No. 135, Jian 1st Rd., Zhonghe Dist., New

Taipei City 23585,Taiwan

Tel: \$\infty +886-2-2226-3630 Fax: +886-2-3234-4842

Sales & Marketing: <u>Contact</u> Technical Support: <u>Home users</u> /

Professional users

The Americas

USA Office

4038 Clipper Court Fremont, CA 94538

Tel: (510) 403-0006

Fax: (510) 403-0022

Sales & Marketing: <u>Contact</u> Technical Support: <u>Home users</u> /

Professional users

Brazil Office

Sales & Marketing: <u>Contact</u>
Technical Support: <u>Home users</u> /
<u>Professional users</u>

Latin America Office

Sales & Marketing: <u>Contact</u> Technical Support: <u>Home users</u> / <u>Professional users</u>

Europe

Head Office EU

AVT Solutions GmbH

Hanauer Landstrasse 291 B 60314

Frankfurt Hessen

Germany

S: technicalsupport_120

Sales & Marketing: Contact

Technical Support: <u>Home users</u> /

Professional users

Russia Office

Sales & Marketing: <u>Contact</u>

Technical Support: <u>Home users</u> / <u>Professional users</u>

Professional Solutions Support Tel:

S+7 (925) 834-0310

Spain Office

AVerMedia Europe Group

Ronda de Poniente no. 4 segundo H

28760 Tres cantos, Madrid

Spain:

S: technicalsupport_120

Sales & Marketing: Contact

Technical Support: Home users /

<u>Professional users</u>

Asia-Pacific

China Office

Room 1510, No.488, Hitech Plaza, South Wuning Rd., Jingan District, Shanghai,

China

Tel: (5)+86-021-5298 7985

Fax: +86-021-5298 7981 Sales & Marketing: <u>Contact</u>

Technical Support: Home users /

Professional users

Japan Office

6F,Kojimachi Syuei Bldg,4-3-13 Kudanminami, Chiyoda-ku, Tokyo ,102-0074,

Japan

Sales & Marketing: Contact

Technical Support: <u>Home users</u> /

<u>Professional users</u>





Limited Product Warranty

AVerMedia provides the one-year product warranty. Should this product, in AVerMedia's opinion, fail to be in the good working order during the warranty period, AVerMedia will, at its option, repair or replace it at no charge, provided that the product has not been subjected to abuse, misuse, accident, disaster, or non-AVerMedia authorized modification or repair.

You may obtain the warranty service by delivering this product to an authorized AVerMedia business partner or to AVerMedia along with the proof of purchase. Product returned to AVerMedia must be pre-authorized by AVerMedia with an RMA (Return Material Authorization) number marked on the outside of the package and sent prepaid, insured, and packaged for the safe shipment. AVerMedia will return the product by prepaid shipment service.

The limited product warranty is only valid over the serviceable life of the product. This is defined as the period during which all components are available. Should the product prove to be irreparable, AVerMedia reserves the right to substitute an equivalent product if available or to retract the product warranty if no replacement is available.

The above product warranty is the only warranty authorized by AVerMedia. Under no circumstances will AVerMedia be liable in any way for any damages, including any lost profits, lost savings, or other incidental or consequential damages arising out of the use of, or inability to use, such product.

Copyright Notice

The information contained in this document is subject to change without notice. AVerMedia shall not be liable for errors contained herein or for incidental consequential damages in connection with the furnishing, performance, or use of this material. This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent by AVerMedia.



Trademark Acknowledgement

AVerMedia acknowledges all the trademarks, registered trademarks, and/or copyrights referred to in this document as the property of their respective owners. Not listing all possible trademarks or copyright acknowledgments does not constitute the lack of acknowledgment to the rightful owners of the trademarks and copyrights mentioned in this document.

ESD Warning

Electronic components and circuits are sensitive to Electrostatic Discharge (ESD). When handling any circuit board assemblies including AVerMedia AVerAI products, it is highly recommended that ESD safety precautions can be observed. ESD safe best practices can include, but are not limited to the following ones.

- 1. Leave the circuit board in the antistatic package until it is ready to be installed.
- 2. Use a grounded wrist strap when handling the circuit board. At a minimum, you need to touch a grounded metal object to dissipate any static charge, which may be present on you.
- 3. Avoid handling the circuit board in the carpeted areas.
- 4. Handle the board by the edges and avoid the contact [sep]with the components.
- 5. Only handle the circuit boards in ESD safe areas, which may include ESD floor and/or table mats, wrist strap stations, and ESD safe lab coats.



1.0 Introduction

AVerMedia AVerAl EN713-AAE9 is a fully featured carrier board developed for NVIDIA Jetson Nano/ Xavier NX module (EN713/NX213B). It is specifically designed to have eight 10/100Mb Ethernet ports with PoE (PSE, Power Sourcing Equipment) support.

Operating with NVIDIA Jetson Nano/ Xavier NX module, EN713-AAE9/EN713/NX213B can process eight channels of 1080p30 video stream, which makes it the perfect choice in building the high performance AI edge computing platform for the intelligent video analytics applications.

EN713-AAE9/ EN713/ NX213B have compact size, which can fit in the compact platform for the commercial and industrial application. And it can operate in the temperature range from -10°C up to 70°C. AVerAI EN713-AAE9/ EN713/ NX213B provides not only the access to a great list of latest interfaces on Nano/ Xavier NX module but also 1x RS-485 interface, 1x micro controller unit (MCU), and 1x RTC battery as the function enrichment.

1.1 Product Specifications

Product Name	Fanless/Fan/Carrier Board	Fanless Box PC	Carrier Board
Product Name	raniess/ran/carrier board	EN713/ NX213B	EN713-AAE9
Core	System on Module (SoM)	Equips NVIDIA® Jetson Nano™/ Xavier NX module	Fully support NVIDIA® Jetson Nano™/ Xavier NX module
	HDMI 2.0 Output	1x HDMI 2.0a/b Type-A supports maximum resolut	ion 3840x2160 at 60Hz
	USB 2.0	1x USB 2.0 Micro-B for recove	ry
	USB 3.0	2x USB 3.0 Type-A	
Front I/O	10/100/1000 BASE-T	1x GbE RJ-45	
	Ethernet	8 ports PoE (8x 10/100 MbE RJ-45 PSE, Power Sourcing E with power budget)	Equipment, IEEE 802.3 AT/AF
	SATA Rev. 3.0	1x	
	Audio	1x Mic-in, 1x Speaker-out	




	RS-485		1x RS-485 Euroblock (3 pins	1
		20 in i		•
	Expansion Header	20 pin wi	th 1x 3.3V UART2, 1x SPI, 1x	125, 2X 12C
	Power Button		1x with a Green color LED	
	Recovery Button		X 1	
Internal PCIe Sockets	Mini-PCIe	Alternative opt	ion: 1x Mini-PCIe slot , Only (for Wi-Fi/BT card, reserved	• •
Power	Power Input	54V/2.78A for Po	oE (PSE, IEEE 802.3 AT/AF wit	th power budget)
Environment	Operating Temperature	-10°C ~ 65°C fanless chassis with AVerCooler™ Wave-Fin	-10°C ~ 65°C Fanless chassis	-10°C ~ 70°C
Liiviioiiiileiit	Storage Temperature		-20°C ~ 85°C	
	Relative Humidity	4	40°C @ 95%, Non-Condensir	ng
Physical	Chassis Dimension	W:212mm x L:196mm x H:60mm (W:226 mm with mounting ears)	W:190mm x L:175mm x H:80mm (W:225mm with mounting ears)	W:170mm x L:170mm x H:4.5mm
Characteristics	Weight	1.25 Kg	4 Kg	269g
	Thermal Solution	With fanless chassis	With fanless chassis	(Optional) with fan module
	Mounting	Desk/Wall/Din Rail	Desk/Wall/Din Rail	N/A
Regulation	EMC/Safety		CE/FCC Class B, KC	•



2.0 Product Overview

2.1 Block Diagram






2.2 Top View of Carrier Board







Bottom View of Carrier Board





2.3 Connector Summary

Designation	Description
J1	RJ45 10/100Mb 4-port Ethernet connector with POE support
J2	RJ45 10/100Mb 4-port Ethernet connector with POE support
J3	RJ45 1Gb single-port Ethernet connector
J5	260-pin SODIMM connector for NVIDIA Jetson Nano/ Xavier NX module
J6	SATA power wafer
J7	Fan wafer
J8	Mic and speaker connector
J9	USB 3.1 Gen 1 2-port connector with 900mA x2
J10	HDMI video output connector
J11	USB/OTG micro-type connector
J12	RS-485 connector
J13	54VDC power Jack
J14	20-pin header UART console for debug, I2C, GPIO
J16	Mini card for USB only
J17	SATA connector
BT1	RTC battery connector


2.4 Switch Summary

Designation	Description
SW8	Force recovery button
SW9	Power on button
SW10	4-pin DIP switch with four sets of setting as defined in Section 3.20.



3.0 Feature Description


3.1 Connector and Switch Locations












3.2 10/100Mb 4-port Ethernet Connectors

Function	10/100Mb 4-port Ethernet connectors, used to connect IP cameras and/or the network switches.
Location	J1 and J2
Type Description	RJ45*4 with integrated magnetics for PoE application
Manufacturer and Part Number	CHAMPWAY, CWJ46614AENL
Mating Connector	Any standard 10/100Mb Ethernet mating connector can be applicable.
Pinout	Comply with Ethernet standards.







Remarks	POE support is enabled on J1 and J2.	

3.3 1Gb single-port Ethernet Connector

Function	1Gb single-port Ethernet connector, used to connect to the host system.	
Location	J3	THE RESIDENCE OF THE PARTY OF T
Type Description	RJ45 with integrated magnetics	TSS26
Manufacturer and Part Number	FOXCONN, JFM38013-0L03-4F-BX3	
Mating Connector	Any standard 1Gb Ethernet mating connector can be applicable.	
Pinout	Comply with Ethernet standards.	
Remarks	None	

3.4 260-Pin SODIMM Connector

Function	Used to mount with and connect to NVIDIA® Jetson Nano/ Xavier NX module.	
Location	J5	
Type Description	260-pin SODIMM connector	
Manufacturer and Part Number	FOXCONN, ASAA826-EASB0-7H	
Mating Connector	DDR4 SO-DIMM 260PIN 9.2mmH STANDARD	84 CHB
Pinout	Please refer to NVIDIA Jetson Nano System-on-Module datasheet for the pinout details.	
Remarks	None	



3.5 SATA Power Wafer and SATA Connector

	2.5" hard drive/S	SSD		
Function	3.5" surveillance			
	J6 (on the left) a	•		
Location	right)	ind 317 (on the		
	SATA HD power (on the left) and		
Type Description	signal (on the rig			
	J6:	,		
Manufacturer and	PINREX, 753-81-	04TW00	110	
Part Number	J17:		48	
	FOXCONN, LE180)77-Z54B-4H		
Mating Connector	4-pin wafer and SATA 3.0 connector		88	
	J6:			
	Pin Number	Description	E 90	11=
	1	5V Power		
Pinout	2	GND		
riiiout	3	GND		
	4	12V Power		
	J17: Please refer to SATA 3.0			
	standard			
Remarks	None			

3.6 Fan Wafer

Function	Fan power and control wafer			
Location	J7			
Type Description	1*4 pin wafer with 1.25 mm pitch			
Manufacturer and	Joint Tech,			
Part Number	A1250WV-04PNI	LNT1N00B		
Mating Connector	(Combination with PINREX's			
Mating Connector	housing)			
	Pin Number Description			
	1	GND		
	2 5V Power			
Pinout	3	TACH from fan		
	3	to module		
	4	PWM from		
	4 module to fan			
Remarks	None			



3.7 Mic and Speaker Connector

Function	Mic and speaker jack	
Location	J8	
Type Description	3.5 mm miniature jack	
Manufacturer and Part Number	JKCR, PJD-035-87HAB	
Mating Connector	2 or 3 conductors type plug	
Pinout	Mic input (on the top) and speaker output (on the bottom)	
Remarks	None	

ELITEPARTNER

3.8 USB 3.1 Gen 1 2-Port Connector

Function	USB 3.1 Gen 1 device connector				
Location	J9				
Type Description	2-port USB Type-A female connector				
Manufacturer and Part Number	CHAMPWAY, CU3B-AFR15U-096H				
Mating Connector	Any USB standard Type-A interface cable or device.				
Pinout	Please refer to USB 3.1 Gen 1 standard.				
Remarks	Support 900mA x2				

3.9 HDMI Video Output Connector

Function	HDMI Type-A TX connector	
Location	J10	
Type Description	HDMI Type-A female connector	
Manufacturer and Part Number	Compupack, ACNHM220028-001	W U
Mating Connector	Any HDMI standard Type-A interface cable or device.	
Pinout	Please refer to HDMI standard.	
Remarks	None	







3.10 USB/OTG Micro-Type Connector

Function	OTG programming recovery	
Location	J11	
Type Description	USB Micro-type female connector	
Manufacturer and Part Number	Fullglory, FG-MCB-111440	
Mating Connector	Any USB standard Micro-type interface cable or device.	
Pinout	Please refer to USB Micro-type standard.	
Remarks	None	

3.11 RS-485 Connector

Function	RS485 interface module UART co	from Jetson Nano ontrol	
Location	J12		
Type Description	3-pin terminal b	lock	
Manufacturer and Part Number	DECA, ME030-3	8103T	
Mating Connector	Combination wire block from DECA	th the plug terminal A	
	Pin Number Description 1 GND 2 B		
Discut			
Pinout			
	3 A		
Remarks			





3.12 54VDC Power Jack

Function	54V DC power ir	nput	
Location	J13		
Type Description	2.5 mm power ja	ack	
Manufacturer and Part Number	JKCR, DCD-020-1	105B	
Mating Connector	Any 2.5mm power plug cable		
	Pin Number Description 3 GND		
Dia cost			
Pinout	1 54V Power		
	2	GND	
Remarks	None		

3.13 20-	Pin Heade	r					
Function	UART con	UART console for debug, I2C, GPIO					
Location	J14						
Туре							
Description	2.54 mm	pitch 2*10	head	der			
Manufacturer and Part Number	COXOC, 3	02AE20PG	AR00	03			
Mating							
Connector	Any 2.5m	m pitch Du	ıPont	t wir	e		
	EN713						
	Address	Pin Name	Pin Name 20-Pin Pin Name Index		Address		
		+3V3	1	2	+5V		
		GND	3	4	GND		
	/dev/i2c-1	I2C1_SDA	5	6	UART2_TXD_3V3	Debug Console	
Pinout		I2C1_SCL	7	8	UART2_RXD_3V3	/dev/ttyS0	
	/dev/i2c-0	I2C0_SDA	9	10	GND		
		I2C0_SCL	11	12	SPI1_SCK	gpio14	
	gpio79	I2S0_SCLK	13	14	SPI1_MISO	gpio13	
	gpio78	I2S0_DOUT	15	16	SPI1_MOSI	gpio12	
	gpio77	I2S0_DIN	17	18	SPI1_CS0	gpio15	
	gpio76	I2SO FS	19	20	SPI1_CS1	gpio232	





ELITE PARTNER

NX213B

Address	Pin Name	20-pin index		Pin Name	Address
	+3V3	1	2	+5V	
	GND	3	4	GND	
/dev/i2c-8	I2C1_SDA	5	6	UART2_TXD	/dev/ttyTCU0
	I2C1_SCL	7	8	UART2_RXD	Debug Console
/dev/i2c-1	I2C0_SDA	9	10	GND	
	I2C0_SCL	11	12	SPI1_SCK	gpio480
					Bidirection
gpio445	I2S0_SCLK	13	14	SPI1_MISO	gpio481
Bidirection					Bidirection
gpio446	I2S0_DOUT	15	16	SPI1_MOSI	gpio482
Bidirection					Bidirection
gpio447	I2S0_DIN	17	18	SPI1_CS0	gpio483
Bidirection					Bidirection
gpio448	12S0_FS	19	20	SPI1_CS1	gpio484
Bidirection					Bidirection

Remarks GPIO uses 3.3V

3.14 Mini Card Connector

Function	LTE or Wi-Fi Module	
Location	J16	
Type Description	Mini-Card for USB	J14
Manufacturer and Part Number	FOXCONN, AS0B221-S68Q-7H	
Mating Connector	Any Mini-Card standard interface device.	
Pinout	Please refer to Mini-Card standard for the pinout details.	
Remarks	Support USB 2.0 only, not PCIe	



3.15 RTC Battery Connector

Function	RTC battery for module	100
Location	BT1	0.00







ELITE PARTNER

Type Description	RTC holder and RTC battery		
Manufacturer and Part Number	Holder: LOTES, AAA-BAT-054-P06 RTC Battery: MITSUBISHI, CR2032 3V		
Mating Connector	Any CR2032 3V battery		
	Pin Number	Description	
Pinout	1	3V Power	
	2	GND	
_	Please be reminded to pay the proper attention on the polarity of this 3'		
Remarks	battery, when it is being replaced. The correct placement is to keep the		
	"+" mark on the battery outward, as shown in the above photo.		





3.16 Force Recovery Button

Function	Force recovery		
Location	SW8		
Type Description	Button		
Manufacturer and Part Number	N/A	Dall bar	
Mating Connector	N/A		
Pinout	N/A		
Remarks	None		

3.17 Power on Button

Function	Power control button	
Location	SW9	
Type Description	Button with Green LED	
Manufacturer and Part Number	N/A	19977710
Mating Connector	N/A	
Pinout	N/A	
Remarks	The green light on LED is activated when the board is powered on.	





3.18 4-Pin DIP Switch

Function	Optional function selection			
Location	SW10		Serie SET	
Type Description	4 SPST DIP switch			
Manufacturer and Part Number	N/A			
Mating Connector	N/A			
Pinout	Please refer to the following table.			
	SW10	Default (OFF)	ON	
	S1	Fan PWM controller	Fan always on	
Remarks	S2	Auto power on	Auto power on disabled	
	S3	RS-485 normal mode	RS-485 terminal mode	
	S4	Test mode off	Test mode on (for the factory use)	

3.19 Other Switch and Jumpers

Other switch and jumpers, such as SW1, JP3, JP4, and JP5, etc. marked on the printed circuit board of EN713-AAE9 carrier board, are reserved for the internal use by AVerMedia. They are not open to the client application.



4.0 Installation

- 1. Check and ensure all the external system power supplies are turned off.
- 2. Install NVIDIA® Jetson Nano/ Xavier NX module onto 260-pin SODIMM connector (J5). Check and be sure to follow the manufacturer's instructions for the proper installation of the mounting hardware, heat sink or heat spreader, fan, and any other applicable requirements from the associated manufacturers.
- 3. Install the necessary cables for the application. The cables can include the following ones. For the additional information of these mentioned cables, please refer to 8.0 Cable Assembly in this manual.
 - Power cable to the input power connector (J13) on the carrier board.
 - HDMI video display cable to HDMI video output connector (J10).
 - Mouse and keyboard cables to USB connectors (J9).
- 4. Connect the power cable to the power adapter.
- 5. Turn on the power adapter. (Please be reminded NOT to power on the system by plugging in the live power.)

5.0 Software

For L4T (Linux for Tegra) BSP and the software support associated with NVIDIA Jetson Nano/ Xavier NX module, please check this link, https://www.avermedia.com/professional/download/nx213b#ans part, to download the file from AVerMedia website.



6.0 Force Recovery Mode

USB 3.I/OTG port (J11) can be used to re-program NVIDIA[®] Jetson Nano/ Xavier NX module by using the other host system running NVIDIA JetpackTM, as the procedure described below.

- 1. Power off the system. Ensure the system power must be completely OFF, instead of staying in the suspend mode or the sleep mode.
- 2. Connect a USB cable from OTG USB port to the other host system which will be used to re-program the new system file into NVIDIA® Jetson Nano/ Xavier NX module.
- 3. Press and hold down Force Recovery Button (SW8) and then power on the carrier board.
- 4. After three seconds, release Force Recovery Button.
- 5. NVIDIA Jetson Nano/ Xavier NX module will show up on the USB list of the host system as a new NVIDIA target device.
- 6. After the system software is updated successfully, please ensure to power off the system. A clean power-on will then revert SEPOTG port back to the host mode.



7.0 Power Consumption

Item Description	Power Consumption	
Theoretical Maximum System Power Consumption	 Maximum power consumption of EN713 is 13.5W (w/ HDMI, RJ45), and embedded w/ POE, that would be extra up to 100W Maximum power consumption of NX213B is 15.2W (w/ HDMI, RJ45), and embedded w/ POE, that would be extra up to 100W (maximum power consumption up to 150W based on adapter) 	
Typical System Power Consumption	The power consumption under the normal operating mode is depending on the application software running with NVIDIA® Jetson Nano /Xavier NX.	